

***** 西铁城 MIYOTA 9T13 9U13 9T15 9U15机心配件列表 *****

原装配件, 日本制造 由MIYOTA表心技术服务中心竭诚为您提供!

<u>PART NAME</u>	<u>中文名称</u>	<u>9T13</u>	<u>9U13</u>	<u>9T15</u>	<u>9U15</u>
BATTERY	电池	280-730	280-450	280-730	280-450
BATTERYCONNECTOR	电池压簧 (负极)	231-368	231-373	231-368	231-373
BATTERY INSULATOR	电极绝缘片	230-220	←	←	←
CALENDAR CORRECTOR LEVER	日历修正杆	116-112	←	←	←
CANNON PINION WITH DRIVING WHEEL	分轮	028-286	←	028-301	←
CLUTCH WHEEL	离合轮	064-790	←	←	←
COIL UNIT	线圈	246-182	246-185	246-182	246-185
DATE DIAL	日历盘	108-E50	108-E60	108-E50	108-E60
DATE DIAL DRIVING WHEEL	日历推动轮	103-111	←	←	←
DATE JUMPER	日历盖板簧	109-500	109-650	109-500	109-650
DIAL GUARD RING	戒子	110-470		110-470	
DIAL WASHER	时轮簧	078-040	←	←	←
ELECTRONIC CIRCUIT UNIT	电路板	279-B320	←	←	←
FIFTH WHEEL AND PINION	五轮	084-700	←	←	←
FOURTH WHEEL AND PINION	秒轮	023-326	←	023-328	←
GUARD FOR DATE DIAL	日历盖板	293-103	293-108	293-103	293-108
HOUR WHEEL	时轮	075-455	←	←	←
INTERMEDIATE WHEEL	快跳轮	087-162	←	←	←
MINUTE WHEEL AND PINION	跨轮	072-121	←	←	←
ROTOR	转子	285-175	←	←	←
SCREW (1)	螺丝	923-112	←	←	←
SCREW (2)	螺丝	930-640	←	←	←
SCREW FOR DATE DIAL GUARD	日历盖板螺丝	929-510	←	←	←
SETTING LEVER	拉档	067-173	←	←	←
SETTING LEVER SPRING	柄轴压片	077-136	←	←	←
SETTING STEM	柄轴	065-495	←	←	←
SETTING WHEEL	拨针轮	076-640	←	←	←
SPACER FOR SETTING STEM	拉档压板簧	212-247	212-264	212-247	212-264
STATOR	线圈固定板	190-152	190-172	190-152	190-172
THIRD WHEEL AND PINION	三轮 (过轮)	017-149	←	←	←
TRAIN WHEEL BRIDGE	上夹板	701-C81	701-E45	701-C81	701-E45
YOKE	离合杆	071-137	←	←	←

MIYOTA表心技术服务中心

地址: 西安市高新六路43号绿港花园2-3-2301#

电话: 029-81873950

<http://www.miyota-sc.com>

E-mail: miyota-sc@miyota-sc.com