

**\*\*\*\*\* 西铁城 MIYOTA FS60/61 机心配件列表 \*\*\*\*\***

**原装配件，日本制造 由MIYOTA表心技术服务中心竭诚为您提供！**

<b>PART NAME</b>	<b>中文名称</b>	<b>FS60/61</b>
ANTI MAGNETIC PLATE	防磁板	<b>186-920</b>
BATTERY	电池	<b>280-390</b>
BATTERY CONNECTOR SPRING	电池负极片	<b>231-381</b>
CALENDAR CORRECTOR LEVER	日历修正杆	<b>116-991</b>
CALENDAR CORRECTOR WHEEL	日历修正轮	<b>213-540</b>
CALENDER PLATE	日历托圈	<b>714-066</b>
CANNON PINION WITH DRIVING WHEEL	分轮	<b>028-345</b>
CENTER WHEEL COCK	中心轮夹板	<b>711-202</b>
CHRONOGRAPH COIL UNIT 1	计时线圈 1	<b>246-207</b>
CLUTCH WHEEL	离合器	<b>064-670</b>
COIL UNIT	线圈	<b>246-207</b>
DATE DIAL	日历盘	<b>108-F4X</b>
DATE DIAL DRIVING WHEEL	日历推动轮	<b>103-994</b>
DATE DIAL GUARD (1)	日历盘压片1	<b>293-993</b>
DATE JUMPER	日历限位簧	<b>109-730</b>
DAY JUMPER	周历限位簧	<b>109-852</b>
DAY WHEEL	周历轮	<b>200-154</b>
ELECTRIC CIRCUIT UNIT	电路板	<b>279-E83</b>
FIFTH WHEEL AND PINION	五轮	<b>084-900</b>
FLY-BACK LEVER	归位杆	<b>260-117</b>
FORTH WHEEL AND PINION	秒轮	<b>023-376</b>
HOUR WHEEL	时轮	<b>075-556</b>
INTERMEDIATE DATE CORRECTING WHEEL	日历修正过轮	<b>087-620</b>
INTERMEDIATE DATE CORRECTING WHEEL 2	日历修正过轮2	<b>087-217</b>
INTERMEDIATE DATE CORRECTING WHEEL 3	日历修正过轮3	<b>087-235</b>
INTERMEDIATE MINUTE WHEEL	传动过轮	<b>087-138</b>
INTERMEDIATE MINUTE-RECORDIMG WHEEL	计分钟快跳轮	<b>087-228</b>
INTERMEDIATE SECOND-RECORDIMG WHEEL (1)	计秒快跳轮	<b>087-226</b>
LEVER STOPPER	制停杆	<b>117-290</b>
MINUTE RECORDING WHEEL	计分钟轮	<b>291-110</b>
MINUTE WHEEL AND PINION	跨轮	<b>072-132</b>
PUSH BUTTON SPACER (FOR FS01/FS11/FS21/FS61)	按钮簧(对FS61)	<b>282-995</b>
ROTOR	转子	<b>285-232</b>
ROTOR FOR CHRONOGRAPH 1	计秒转子 (1)	<b>285-233</b>
SCREW FOR CENTER WHEEL COCK 1(X2)	中心轮夹板螺丝1(X2)	<b>923-980</b>
SCREW FOR CHRONOGRAPH GURD 1	计时压板螺丝1	<b>930-650</b>
SCREW FOR CHRONOGRAPH GURD 2	计时压板螺丝2	<b>929-490</b>
SCREW FOR DATE DIAL GUARD (X3)	日历压板螺丝(X3)	<b>929-640</b>

**原装配件，日本制造 由MIYOTA表心技术服务中心竭诚为您提供！**

MIYOTA表心技术服务中心

地址：西安市高新六路43号绿港花园2-3-2301#

电话：029-81873950

网址：www.miyota-sc.com

E-mail：miyota-sc@miyota-sc.com

<b><u>PART NAME</u></b>	<b>中文名称</b>	<b><u>FS60/61</u></b>
SCREW FOR ELECTRIC CIRCUIT (X2)	电路板螺丝	<b>922-166</b>
SCREW FOR TRAIN WHEEL BRIDGE 1	上夹板螺丝1	<b>923-980</b>
SCREW FOR TRAIN WHEEL BRIDGE 2	上夹板螺丝2	<b>934-470</b>
SECOND CHRONOGRAPH WHEEL	计秒轮	<b>251-240</b>
SECOND WHEEL	秒轮	<b>025-119</b>
SETTING LEVER	拉档	<b>067-993</b>
SETTING STEM	柄轴	<b>065-549</b>
SETTING WHEEL	拨针轮	<b>076-680</b>
SPACER FOR SETTING STEM	柄轴压板	<b>212-A02</b>
STATOR	定子	<b>190-203</b>
STATOR FOR CHRONOGRAPH 1	计时定子(1)	<b>190-205</b>
STOP LEVER	停止杆	<b>204-550</b>
STOP SPRING	停止簧	<b>903-228</b>
SUPPORTER FOR PLATE COMPLETE	机芯托板	<b>226-508</b>
SUPPORTOR FOR CHRONOGRAPH PLATE	计时支撑板	<b>720-723</b>
THIRD WHEEL AND PINION	三轮 (过轮)	<b>017-171</b>
TRAIN WHEEL BRIDGE	上夹板	<b>701-F39</b>
YOKE	离合杆	<b>071-144</b>
LONGER SETTING STEM(24.00MM)	长柄轴	<b>065-557</b>

MIYOTA表心技术服务中心

地址：西安市高新六路43号绿港花园2-3-2301#

电话：029-81873950

网址：www.miyota-sc.com

E-mail：miyota-sc@miyota-sc.com