

***** 西铁城 MIYOTA OS90机心配件列表 *****

原装配件, 日本制造 由MIYOTA表心技术服务中心竭诚为您提供!

PART NAME	中文名称	OS90
ALARM MARKING WHEEL	鸣闹轮	
ALARM MARKING WHEEL GUARD	鸣闹轮盖板	
BATTERY	电池	280-440
BATTERY CONNECTOR SPRING	电池负极片	231-345
BUZZER CONTACT SPRING	蜂鸣器连接簧	
BUZZER TERMINAL PLATE	蜂鸣器终止簧	
CALENDAR CORRECTOR LEVER	日历修正杆	116-106
CALENDAR CORRECTOR WHEEL	日历修正轮	213-380
CANNON PINION WITH DRIVING WHEEL	分轮	028-218
CENTER WHEEL COCK	中心轮夹板	711-166
CHRONOGRAPH COIL UNIT 1	计时线圈 1	246-148
CHRONOGRAPH COIL UNIT 2	计时线圈 2	
CHRONOGRAPH WHEEL	计时轮	251-100
CIRCUIT INSULATER	线圈绝缘片	
CLUTCH WHEEL	离合轮	064-670
COIL UNIT	线圈	246-147
CONTACT SPRING	连接簧	
DATE DIAL	日历盘	108-A0XX
DATE DIAL DRIVING WHEEL	日历推动轮	103-105
DATE DIAL GUARD (1)	日历盘压片 1	293-990
DATE DIAL GUARD (2)	日历盘压片 2	713-107
DATE JUMPER	日历盘限位簧	109-580
ELECTRIC CIRCUIT UNIT	电路板	279-935
FIFTH WHEEL AND PINION	五轮	084-640
FLY-BACK CONNECTION LEVER	归位连接杆	270-060
FLY-BACK LEVER	归位杆	260-116
FORTH WHEEL AND PINION	秒轮	023-267
HOUR RECORDING WHEEL	计时轮	
HOUR WHEEL	时轮	075-392
INTERMEDIATE CHRONOGRAPH WHEEL	计时快跳轮	087-154
INTERMEDIATE DATE CORRECTING WHEEL	日历修正过轮	087-620
INTERMEDIATE HOUR-RECORDING WHEEL 1	计小时快跳轮 (1)	
INTERMEDIATE HOUR-RECORDING WHEEL 2	计小时快跳轮 (2)	
INTERMEDIATE HOUR-RECORDING WHEEL 3	计小时快跳轮 (3)	
INTERMEDIATE MINUTE WHEEL	分钟快跳轮	087-138
INTERMEDIATE MINUTE-RECORDING WHEEL	计分钟快跳轮	087-134
INTERMEDIATE SECOND-RECORDING WHEEL	计秒快跳轮	087-141
MINUTE RECORDING WHEEL	计分钟轮	291-060
MINUTE WHEEL AND PINION	跨轮	072-114
ROTOR	转子	285-146
ROTOR FOR SECOND CHRONOGRAPH	计时转子 (1)	285-159
ROTOR FOR CHRONOGRAPH	计时转子 (2)	285-151
SCREW FOR CENTER WHEEL COCK (X3)	中心轮夹板螺丝(X3)	923-980

MIYOTA表心技术服务中心

地址: 西安市高新六路43号绿港花园2-3-2301#

电话: 029-81873950

网址: www.miyota-sc.com

E-mail: miyota-sc@miyota-sc.com

原装配件, 日本制造 由MIYOTA表心技术服务中心竭诚为您提供!

接上页

PART NAME	中文名称	OS90
SCREW FOR CHRONOGRAPH COIL UNIT 1	计时线圈螺丝1	923-990
SCREW FOR CHRONOGRAPH COIL UNIT 2(X2)	计时线圈螺丝2(X2)	
SCREW FOR CHRONOGRAPH GURD(X4)	计时盖板螺丝(X4)	923-980
SCREW FOR COIL UNIT	线圈螺丝	923-990
SCREW FOR DATE DIAL GUARD (X3)	日历盖板螺丝(X3)	929-480
SCREW FOR ELECTRIC CIRCUIT (X2)	电路板螺丝(X2)	923-990
SCREW FOR TRAIN WHEEL BRIDGE (X3)	主夹板螺丝(X3)	923-980
SECOND CHRONOGRAPH WHEEL	计秒轮	251-090
SECOND WHEEL	秒轮	025-950
SETTING LEVER	压制杆	067-162
SETTING STEM	柄轴	065-441
SETTING WHEEL	拨针轮	076-680
SPACER FOR ELECTRIC CIRCUIT 1 (X2)	电路板簧片(1)(X2)	027-111
SPACER FOR ELECTRIC CIRCUIT 1 (X3)	电路板簧片(1)(X3)	
SPACER FOR ELECTRIC CIRCUIT 2	电路板簧片(2)	027-112
SPACER FOR SETTING STEM	中间压板	212-208
STATOR	定子	190-126
STATOR FOR CHRONOGRAPH 1	计时定子(1)	190-128
STATOR FOR CHRONOGRAPH 2	计时定子(2)	190-131
STOP LEVER	停止杆	204-530
SUPPORTER FOR PLATE COMPLETE	机芯托板	226-343
SUPPORTOR FOR CHRONOGRAPH PLATE	计时支撑板	720-717
THIRD WHEEL AND PINION	三轮 (过轮)	017-142
TRAIN WHEEL BRIDGE	上夹板	701-875
YOKE	离合杆	071-128
LONGER SETTING STEM(24.00MM)	长柄轴	065-533

MIYOTA表心技术服务中心

地址: 西安市高新六路43号绿港花园2-3-2301#

电话: 029-81873950

网址: www.miyota-sc.com

E-mail: miyota-sc@miyota-sc.com